

Unit 1, AMC Business Park

12 Cumberland Avenue

Park Royal, London, NW10 7QL

t: 0208 621 6210 f: 0208 621 6211

w: www.doorentrydirect.com

5200M Time clock module - Installation Instructions

IN5200M 20120504

Operating Instructions

Thank you for your confidence in our product. We would like to ensure that you obtain the best possible result from your investment.

Caution

- Press RESET button before use.
- Recharge the clock battery when no indicators appear in the display for at least 20 minutes. After applying power for the first time allow 16 hours to gain a full charge
- The relay will only switch on for the first time when the time set (for the ON period) is reached. If you want the time clock ON period NOW... press the MANUAL button at the end of programming.

Wiring Instructions

Below is an example of the 5200 time clock fitted into telephone entry system for "Tradesman" facility. When the clock displays ON the NO and C terminals are closed.

Power Connection

This unit may be connected to low voltage power supplies (12v ac or 12v dc). Red LED indicates that voltage is present.

| Terminal | Function |
|----------|----------------------|
| 0 | 12v ac or -ve 12v dc |
| 12 | 12v ac or +ve 12v dc |

Output Connection

Green LED indicates that the relay is energised. Maximum current across the contact is 1 ampere at 24v dc.

| - | |
|----|-------------------------|
| С | Common |
| NC | Normally Closed Contact |
| NO | Normally Open Contact |
| | |

Relay Function

Warranty

Terminal

The unit is supplied with 12 months warranty against defects in manufacture.

EC Compliance

This item has been classified as a 'component'and is not within the scope of the EMC directive 89/336/EEC.

Safety

It is important to disconnect mains power before attempting to remove any fuses. This unit should only be connected to low voltage power supplies (12v ac or 12v dc).

Setting the Digital Timer

| CLOCK | current time setting or show |
|-------|------------------------------|
| | current time |

| PROG | press this button to e | nter pro- |
|------|------------------------|-----------|
| | gramme mode. There | e are 8 |

on/8 offs for each program the day of the week setting

button

DAY

HOUR hour setting button MIN minute setting button MANUAL ON/OFF select mode RESET button to cancel all prior set-

tings

ON LED lamp indicator. LED light on when the device is turned

Set Current Time and Day

- Press CLOCK and DAY buttons until current day shows. Release both buttons for current day (today) setting.
- Press CLOCK and HOUR buttons until current hour shows. Release both buttons for current hour (now) settina.
- Press CLOCK and MIN buttons until current minute shows. Release both buttons for current day (now) setting.
- After setting the weekday and the time, the second will reset automatically.

MANUAL button

- Press MANUAL button to override ON/AUTO/OFF mode.
- On mode is to turn on the device. Off mode is to turn off the device.
- When using MANUAL button to turn device on if already off or off if already on, timer automatically resumes program on next cycle.

| Program | Мо | Tu | We | Th | Fr | Sa | Su |
|---------|----|----|----|----|----|----|----|
| 1 | √ | √ | √ | √ | √ | √ | √ |
| 2 | √ | | | | | | |
| 3 | | √ | | | | | |
| 4 | | | √ | | | | |
| 5 | | | | √ | | | |
| 6 | | | | | √ | | |
| 7 | | | | | | √ | |
| - 8 | | | | | | | √ |
| 9 | √ | √ | √ | √ | √ | | |
| 10 | | | | | | √ | √ |
| 11 | √ | √ | √ | √ | √ | √ | |
| 12 | √ | | √ | | √ | | |
| 13 | | √ | | √ | | √ | |
| 14 | √ | √ | √ | | | | |
| 15 | | | | √ | √ | √ | |

Set Programs

- Press PROG button and "1 on" will appear at the left side of display. This is the time that you desire the device to turn on.
- Press DAY button to select the PRO-GRAM. There are 15 programs from which to choose:
- Press HOUR button to set hour.
- Press MIN button to set minute.
- After setting the "1 on" program, press the PROG button again and "1 off" will appear. This is the time that you desire the device to turn off.
- Repeat 2 4 until the off time is set. The PROGRAM selected for OFF should matche the PROGRAM selected for ON.
- Your timer gives you up to 8 different on and 8 different offs'. You can use all 8 settings per period, or as few as you like.

Review your Programs

- Press PROG button to advance display to each subsequent on or off set-
- Check days and times displayed.
- To make a change follow instructions under "SET PROGRAMS".

