



NOTE :

- ) Utilizzando AN1000, AN9300, AN7320 (anche affiancati a MV70) : tagliare il ponticello di rame presente sul circuito stampato del citofono
- ) Nella "DE80" sfilare il jumper "PM" e regolare al minimo il Timer (agendo in senso antiorario)
- ) In impianti con SD55, controllare che nei monitor MV80, MV100 lo switch sia posizionato su "L"
- ) Se in pulsantiera e' presente il Posto Esterno a 1 tasto : eliminare il collegamento gia' presente tra il morsetto "CD" del posto esterno e le piastre diodi, ed eseguire i collegamenti richiesti dallo schema

NOTES :

- ) When using AN1000, AN9300, AN7320 (also if combined with MV70): cut jumper wire on door phone pcbard
- ) In "DE80", remove "PM" jumper and set Timer to minimum (counterclockwise)
- ) In systems with SD55 video distributors, set the switch of MV80, MV100 monitors to "L" position
- ) If panel module has 1 call button: remove existing connection between CD terminal of panel and diode plates, and connect as shown in diagram

IMPIANTO VIDEOCITOFONICO ( SISTEMA "5 fili" ),  
 con 2 POSTI ESTERNI VIDEO , 1 COLONNA  
 "5 wires" VIDEO DOORPHONE SYSTEM ,  
 WITH 2 VIDEO VISITOR PANELS, 1 RISER