



VIP

Door Entry Direct Bite Size Training

Mark Morton-Smith
Comelit Trainer

System Features & Functions

Additional Functions

As well as all of the standard intercom functions: Audio, Video Lock Release etc...


There are a range of additional functions. Some are device specific please check if required:

- Video Memory Function or answer machine. If a call is made and is not answered the internal monitor can record a 10 second Video and Audio clip
- Away Message. The internal device can be used to record a message , which if activated will play back out of the speaker in the entrance panel if a call is made to this address
- Intercommunication between Internal devices either at the same address, or different addresses. A directory can be programmed in to the menu allowing the user to select who to call
- Call Diversion. If a call isn't answered after a programmed time (or the device is busy) the call can be forwarded to another device on the network
- Voice Annunciation & LED Indication at Entrance Panels. To help to comply with the equality act, Voice + LED indication is available to let the visitor know that a call has been placed, answered/busy, and if the door is being released
- Hearing Loop option available. All Video monitors have a built in hearing loop as standard to allow users with hearing aids to amplify the volume. If required a hearing loop module can be added to Entrance Panels

System Features & Functions

SIP Interface

- SIP stands for Session Initiation Protocol
- It is an IP protocol used for communication across a network
- Comelit VIP is also a protocol, and we require an interface to convert from VIP to SIP
- We normally use SIP in 1 of 2 ways.
 - Calls to IP Phone systems
 - Calls to 3rd party home automation systems
 - Crestron / RTI / Control 4 / Gira



System Features & Functions

Call Log NVR

- Allows the recording, storage and playback of calls from external units
- Possibility to install on a ViP system as a “Door Entry NVR”
- All calls and activity from the panels will be recorded on this NVR
- Any PC with Call Log Client SW can connect to Call Log NVR and upload data
- Video and audio recording



System Features & Functions

VIP – Fire Interface 1467

- 1467 interface allows to forward events generated by the Fire detection system to the VIP door entry system
- This is not part of the Fire alarm system – But an addition
- Requires Mini or Maxi Monitor
- Comelit Atena or Logifire Panels
- The 5 types of events reported on VIP devices are
 - Pre-alarm
 - Alarm
 - Evacuation
 - Fault - General fault from Fire control panel - **only to CPS**
 - Communication error - Connectivity problems with Fire control panel - **only to CPS**




System Features & Functions

Virtual Keys

App Feature

- VIP Only
- 1456B – M.U.G required
- 316 Range / 3360B / Ultra systems
- 6 digit code – randomly generated
- Time + Date restrictions if required
- QR code – Ultra Panels Only
- Send to visitor via email, Facebook WhatsApp etc



Pier Davide Menolfi ti ha condiviso una Virtual Key per accedere al

Condominio

Appartamento

Pier House

Apartment 1

Valida da

Fino a

23 Mar 2021, 08:10

30 Mar 2021, 10:30

Codice

564174

Comelit

Any Questions?

WITH
YOU
ALWAYS



WITH
YOU
ALWAYS

Thank You!