


## Art.3123 Telephone



**Three position volume control:**

Use this to adjust the incoming call volume.

- HIGH
- MEDIUM
- LOW

**Door release:**

Pressing this button during a call will release the door.

**Spare service button**

**Privacy LED:**

Red LED indicates if privacy switch is on or off.

**Privacy Switch:**

Slide this switch to activate/deactivate the telephone.

**IMPORTANT NOTE:** The incoming call tone comes out of the telephone ear piece.

Do not hold the hook switch down while holding the telephone to your ear.

### ANSWERING A CALL

**STEP 1**

An incoming call will be signalled by an audible tone from the handset



**STEP 2**

Pick up the handset and speak with the caller



**STEP 3**


To open the door press the  button  
To end the call simply hang up



### USING THE PRIVACY FACILITY

**STEP 1**

To activate the privacy facility (ie. No calls will be received) Move the slide switch to the OFF position, This will illuminate the privacy on LED.



**STEP 2**

To deactivate the privacy facility move the slide switch to the ON position. This will allow calls to be received and the privacy on LED will turn off.

