


Art.5112 Eclipse intercom



Spare service button:

Talk Button:

Pressing this button after a call is made will open the speech path from the door. To talk to the caller press and hold the button and to listen to the caller release this button.

Spare service button:

Privacy LED:

Door release button:

Pressing this during a call will open the door.

Speak LED

Ring volume and mute switch

Door open LED

ANSWERING A CALL

STEP 1

An incoming call will be signalled by an audible tone from the Eclipse audio intercom.

STEP 2

Press the talk button to answer the call and activate simplex speech mode. To talk to the caller press and hold the talk button and to listen to the caller release the talk button.

STEP 3

To open the door press the button. The eclipse intercom will switch off when the timeout expires.

USING THE PRIVACY FACILITY

STEP 1

To increase the volume of the call tone move the slide switch to the larger of the two bell symbols . To activate the privacy facility move the slide switch to the Mute position.

STEP 2

To deactivate the privacy facility simply move the slide switch back to either the low or high call tone setting.