


Connection of SRS DC50 or DC60SS keypads in parallel

## Installation Notes

### Cable

On keypad is treated as the master and will control the lock. Any other devices (egress button, door entry system etc.) will act as slave to this keypad. The slave keypad uses the output relay to trigger the egress input on the Master keypad



Set Lock Time to 1 second

Connect lock as per DC60 instructions