

## Handset Compatibility Chart for use with Golmar Universal Handsets

Handset	Lock	Mic.	Comm.	Speaker	Buzzer	Tone
Golmar Universal T-710R	P1	5	3	10	7	0
Golmar Universal T-910R	P1	5	3	10	7	0
Acet	5	10	2	7	9	
Auta	10	3	4	7	12	
Bpt	2	1	4	5	3	
BSTL	Z	R	O	T	I	
Centramatic	4	2	1	3	5	
Comelit	5	2	4	3	1	
Comelit VOX2000	P1	3	4	2	Zoemer	
Elvox	2	6	9	4	+	
Entryphone	3	P	B.F.G	L	A	
Farfisa	5	1	3	2	6	
Fermax Gondola	4	1	3	2	Vo5	
Fermax TF-1Z	1	2	3	6	4	
Fermax TN-1 *	1	2	3	6		4
Fermax TN-Z	1	2	3	6	4	
Golmar M-500	4	5	3	10	7	
Golmar T-600	T	1	3	2	6	
Golmar T-800	P1	5	3	10		0
Golmar T-810	P1	5	3	10	7	
Golmar T-810R	P1	5	3	10	7	0
Golmar T-900	P1	5	3	10		0
Golmar T-910	P1	5	3	10	7	
Golmar T-1000	X	M	A	5	N	
Golmar T-1000A	11	5	3	10	12	
Golmar T-2800	4	5	3	10	7	
Golmar T-2802	4	5	3	10	7	
LT Terraneo	T1	1	3	2	6	
Selti	5	1	3	2	6	
Siedle	1	2	9/C	11	7	
STR NH200/205	I	M	O	T	S	
Techniphone	5	1	3	2	V	
Tegui GL	3	4	2	5	1	
Tegui Horizon Z	3	4	2	5	1	
Tegui Horizon E	3	4	2	5		1
Urmet	9	2	6	1		CA
Urmet	8/9	2	11	1	7	
Videx	5	1	3/7	2	6	

**\* Fermax TN-1 Set JP1 jumper between 2 and 3. Do not change JP1 position for other models**