


SRS panel housing Comelit audio/video module and DC50 keypad + DC260 door controller

### Installation Notes

- REFER TO COMELIT INSTRUCTIONS. This diagram is a quick guide to connecting the keypad.
- Lock release time is set in 4680C programming procedure.
- set lock time on both units to 1 second.



Remember to set lock time on DC50 unit to 1 second.



Remember to set lock time on DC260 unit to 1 second.