

## X-air brings the latest innovation from BPT allowing video entry calls to be answered directly from a tablet or smartphone

Compatible with Android or Apple devices, X-Air takes video entry to the next level of innovation. Exceptional quality images and audio are transmitted directly to your tablet or smart phone, allowing two way conversation and door release functions

Video calls can be transferred between devices, remote cameras can be viewed, in fact, all the functions you would expect from a standard monitor are at your fingertips. Using a standard wireless router, the X-Air apps work on their own or side by side with traditional hard wired monitors to give the ultimate flexibility. Standard X-Air kits can call up to 3 individual smart devices as well as any number of BPT monitors and are compatible with the entire BPT range.

- Easy to buy kits
- Kit includes entry panel X1 monitor
- Fast installation

- WIFI compatible
- Works with up to 3 devices inside the accommodation
- Expandable IP intercom






X-Air PLUS+ miniserver technology builds on the features of X-Air, allowing up to ten devices to be called. Significantly, X-Air plus can also integrate seamlessly with Crestron touchscreens without the need for a full BPT server.

A mixture of tablets, smartphones, Crestron devices and traditional monitors can be used in harmony, making X-Air Plus+ the most cutting edge and versatile home entry solution for any situation. The miniserver can also act as a secure network device, providing LAN isolation within an apartment to ensure privacy from the building network in multi apartment installations. X-Air PLUS+ can also utilise the full functionality of the XiP porter system, allowing seamless interaction in apartment block layouts.

- Compatible with Apple and Android devices
- Crestron compatible (X-Air PLUS+)
- A full range of kits

- Thangram or VR panel options
- WIFI compatible
- Fast installation

# X-AIR ENTRY SYSTEM COMPONENTS



BPT System Technology

IP TERMINAL

ETHERNET

**SWITCH** 

ETI/MINISER

OPALE

ETHERNET

SWITCH

XIP/PORTER

The ETI/miniSER works



10 DEVICES

BUILDING

**SETUP** 

### ETI/miniSER is set in "dual-network" mode. Home LAN is separated from common LAN. Each miniSER, one for each apartment, can manage calls to mobile devices as well as to third party terminals. ETI/SER Xip instead manages the concierge station and the call routing from the entry panels to the X1 receivers. ETI/SER XIP



X-AIR PLUS SYSTEM COMPONENTS

WIRELESS ACCESS

POINT ROUTER

VA/08

OPALE

VA/08

ETI/XIP

ETI/XIP

OPALE



- Easy to buy kits
- Kit includes 1 fixed monitor as standard
- 3 device licenses included in standard kit
- Non expandable and not AV compatible
- IP intercom

(For >3 devices or AV integration, please see X-AIR PLUS+ overleaf)

## X-AIR Entry Kits

### SEE PAGE 290 FOR DETAILS

X-AIR is BPT's all new XIP app that allows residents entry control from the comfort of their sofa. A hard wired door entry panel and monitor system couples with an XIP system, the LAN (local area network) and X-AIR to provide wireless devices the capabilities to control entry.

# THANGRAM X-AIR KIT

Panel	Monitor	Code
	AGATA VC	XTBAG
6	PERLA BLACK	XTBPB
	PERLA WHITE	XTBPW
	OPALE WHITE	XTBOW
	OPALE WHITE (WIDE)	XTBOWW
	OPALE BLACK	XTBOB
	OPALE BLACK (WIDE)	XTBOBW

### KIT INCLUDES:

- DVC/08KME
- Required Monitor (see table below)
- DPH DTH ME

DCI DPF NF VA/08K ETI/XIP APP

## THANGRAM KEYPAD X-AIR KIT

Panel	Monitor	Code
	AGATA VC	XTBKAG
6	PERLA BLACK	XTBKPB
	PERLA WHITE	XTBKPW
	OPALE WHITE	XTBKOW
	OPALE WHITE (WIDE)	XTBKOWW
20 19 90 20 19 90	OPALE BLACK	XTBKOB
	OPALE BLACK (WIDE)	XTBKOBW

### KIT INCLUDES:

- DVC/08KME
- Required Monitor (see table below) DPH DTH ME

  - DSI DCI

- DPF NF VA/08K
- ETI/XIP APP R/1
- PCS/XIP

AGATA VC	• • •	PERLA BLACK	CO.	OPALE BLACK	Ţ	OPALE BLACK (WIDE)	
-		PERLA WHITE	28	OPALE WHITE		OPALE WHITE (WIDE)	

## VANDAL RESISTANT X-AIR KIT

Panel	Monitor	Code
	AGATA VC	XVRAG
9	PERLA BLACK	XVRPB
	PERLA WHITE	XVRPW
	OPALE WHITE	XVROW
0	OPALE WHITE (WIDE)	XVROWW
	OPALE BLACK	XVROB
	OPALE BLACK (WIDE)	XVROBW

## VANDAL RESISTANT KEYPAD X-AIR KIT

Panel	Monitor	Code
in the second	AGATA VC	XVRKAG
	PERLA BLACK	XVRKPB
0	PERLA WHITE	XVRKPW
	OPALE WHITE	XVRKOW
333	OPALE WHITE (WIDE)	XVRKOWW
2	OPALE BLACK	XVRKOB
S. Control of the Con	OPALE BLACK (WIDE)	XVRKOBW

### KIT INCLUDES:

- VRVX/1 Required Monitor (see table below) VRSH/1
- DMVC/08K
- ETI/XIP APP

### KIT INCLUDES:

- VRVKX/1
- Required Monitor (see table below) VRSH/2

•	VA/08K
•	ETI/XIP API
•	R/1
•	PCS/XIP

AGATA VC	Pe	PERLA BLACK	<b>I</b>	OPALE WHITE		OPALE BLACK (WIDE)	
-		PERLA WHITE	<b>28</b>	OPALE BLACK	-0-	OPALE WHITE (WIDE)	<b>B</b>

## SATIN BLACK X-AIR KIT

Panel	Monitor	Code
	AGATA VC	XBLAG
	PERLA BLACK	XBLPB
	PERLA WHITE	XBLPW
<b></b>	OPALE WHITE	XBLOW
à	OPALE WHITE (WIDE)	XBLOWW
	OPALE BLACK	XBLOB
	OPALE BLACK (WIDE)	XBLOBW
חבב חרוויפון וו וויפודי	e	

# SATIN BLACK KEYPAD X-AIR KIT

Panel	Monitor	Code
	AGATA VC	XBLKAG
	PERLA BLACK	XBLKPB
9.4	PERLA WHITE	XBLKPW
	OPALE WHITE	XBLKOW
9	OPALE WHITE (WIDE)	XBLKOWW
	OPALE BLACK	XBLKOB
	OPALE BLACK (WIDE)	XBLKOBW

### KIT INCLUDES:

- Required Monitor (see table below) BLSH/1
- VA/08K ETI/XIP APP R/1

### KIT INCLUDES:

- BLVKX/1 Required Monitor (see table below) BLSH/2 DMVC/08K
- ETI/XIP APP R/1 PCS/XIP

DMVC/08K		N/I		• DMVC/08K			s/XIP
AGATA VC	000	PERLA BLACK	<b>E</b>	OPALE BLACK	7	OPALE BLACK (WIDE)	<b>13</b>
-		PERLA WHITE	28	OPALE WHITE	5	OPALE WHITE (WIDE)	<b>8</b>

## HIGHLY POLISHED X-AIR KIT

Panel	Monitor	Code
	AGATA VC	XHPAG
00	PERLA BLACK	XHPPB
	PERLA WHITE	XHPPW
.1111	OPALE WHITE	XHPOW
ů.	OPALE WHITE (WIDE)	XHPOWW
	OPALE BLACK	XHPOB
	OPALE BLACK (WIDE)	XHPOBW

## HIGHLY POLISHED KEYPAD X-AIR KIT

Panel	Monitor	Code
	AGATA VC	XHPKAG
	PERLA BLACK	XHPKPB
	PERLA WHITE	XHPKPW
man.	OPALE WHITE	XHPKOW
対策 対策第 対策第	OPALE WHITE (WIDE)	XHPKOWW
. 10	OPALE BLACK	XHPKOB
	OPALE BLACK (WIDE)	XHPKOBW

### KIT INCLUDES:

- HPVX/1 Required Monitor (see table below) HPSH/1 DMVC/08K
- VA/08K ETI/XIP APP R/1

ETI/XIP APP R/1

## KIT INCLUDES:

- HPVKX/1 Required Monitor (see table below) HPSH/2 DMVC/08K
- VA/08K ETI/XIP APP R/1 PCS/XIP

AGATA VC	<b>F3</b>	PERLA BLACK		OPALE BLACK	7	OPALE BLACK (WIDE)	<b>.</b>
-		PERLA WHITE	28	OPALE WHITE	. 0 .	OPALE WHITE (WIDE)	

## CLASSIC BRASS X-AIR KIT

Panel	Monitor	Code
	AGATA VC	XBRAG
	PERLA BLACK	XBRPB
	PERLA WHITE	XBRPW
.1111	OPALE WHITE	XBROW
6	OPALE WHITE (WIDE)	XBROWW
	OPALE BLACK	XBROB
	OPALE BLACK (WIDE)	XBROBW

## CLASSIC BRASS KEYPAD X-AIR KIT

Panel	Monitor	Code
	AGATA VC	XBRKAG
	PERLA BLACK	XBRKPB
	PERLA WHITE	XBRKPW
-1711	OPALE WHITE	XBRKOW
111	OPALE WHITE (WIDE)	XBRKOWW
	OPALE BLACK	XBRKOB
	OPALE BLACK (WIDE)	XBRKOBW

### KIT INCLUDES.

- BRVX/1 Required Monitor (see table below)
  BRSH/1
  DAMAC (08)

Required Monitor (see table below)

•	VA/08K
•	ETI/XIP APF
•	R/1
_	DCC (VID

DMVC/08K				DMVC/08K		PCS	D/XIP
AGATA VC	<b>S</b>	PERLA BLACK		OPALE BLACK		OPALE BLACK (WIDE)	7
-	V	PERLA WHITE	[27]	OPALE WHITE	<b>E</b>	OPALE WHITE (WIDE)	

compatible:



- Easy to buy kits
- Kit includes 1 fixed monitor as standard
- Crestron and third party compatible
- 6 device licenses included in standard kit
- Expandable up to 10 devices maximum
- IP intercom

### X-AIR PLUS+ Kits

### SEE PAGE 290 FOR DETAILS

X-AIR is BPT's all new XIP app that allows residents entry control from the comfort of their sofa. A hard wired door entry panel and monitor system couples with an XIP system, the LAN (local area network) and X-AIR to provide wireless devices the capabilities to control entry.

## THANGRAM X-AIR+ KIT

Panel	Monitor	Code
	AGATA VC	XPTBAG
6	PERLA BLACK	XPTBPB
	PERLA WHITE	XPTBPW
	OPALE WHITE	XPTBOW
	OPALE WHITE (WIDE)	XPTBOWW
	OPALE BLACK	XPTBOB
	OPALE BLACK (WIDE)	XPTBOBW

## THANGRAM KEYPAD X-AIR+ KIT

Panel	Monitor	Code
	AGATA VC	XPTBKAG
6	PERLA BLACK	XPTBKPB
	PERLA WHITE	XPTBKPW
11111	OPALE WHITE	XPTBKOW
10.00	OPALE WHITE (WIDE)	XPTBKOWW
20110	OPALE BLACK	XPTBKOB
	OPALE BLACK (WIDE)	XPTBKOBW

### KIT INCLUDES:

•	DVC/U8KME
•	Required Monitor (see table below)
•	DPH '
•	DTH ME
•	DSI
•	DCI
•	PCS/XIP

DPF NF VA/08K ETI/XIP R/1 MINI SER

### KIT INCLUDES:

•	DVC/08KME Required Monitor (see table below) DPS DNA ME DSI
•	DCI
•	VAS/101

DPF NF VA/08K ETI/XIP MINI SER

AGATA VC	000	PERLA BLACK		OPALE BLACK	7	OPALE BLACK (WIDE)	8
-		PERLA WHITE	£8	OPALE WHITE	8	OPALE WHITE (WIDE)	

## VANDAL RESISTANT X-AIR+ KIT

Panel	Monitor	Code
	AGATA VC	XPVRAG
0	PERLA BLACK	XPVRPB
	PERLA WHITE	XPVRPW
	OPALE WHITE	XPVROW
0	OPALE WHITE (WIDE)	XPVROWW
Common or other party of the common of the c	OPALE BLACK	XPVROB
	OPALE BLACK (WIDE)	XPVROBW

## VANDAL RESISTANT KEYPAD X-AIR+ KIT

Panel	Monitor	Code
in the second	AGATA VC	XPVRKAG
	PERLA BLACK	XPVRKPB
	PERLA WHITE	XPVRKPW
	OPALE WHITE	XPVRKOW
111	OPALE WHITE (WIDE)	XPVRKOWW
	OPALE BLACK	XPVRKOB
	OPALE BLACK (WIDE)	XPVRKOBW

### KIT INCLUDES:

•	VRVX/1
•	Required Monitor (see table below)
•	VRSH/1
•	DMVC/08K
•	VA/08K

### KIT INCLUDES:

•	VRVKX/1
•	Required Monitor (see table below)
•	VRSH/2
•	DMVC/08K
•	VA /08 V

•	ETI/XIP
	R/1
	MINI SER
	PCS/XIP
	VAS/101

*/ () OOI (		V/ (5/ 10		V/ V 00 11		***	37 101
AGATA VC		PERLA BLACK	Mil.	OPALE BLACK	-:	OPALE BLACK (WIDE)	3
-		PERLA WHITE	28	OPALE WHITE	- 0 -	OPALE WHITE (WIDE)	

# SATIN BLACK X-AIR+ KIT

Panel	Monitor	Code
	AGATA VC	XPBLAG
	PERLA BLACK	XPBLPB
. ė	PERLA WHITE	XPBLPW
	OPALE WHITE	XPBLOW
	OPALE WHITE (WIDE)	XPBLOWW
	OPALE BLACK	XPBLOB
	OPALE BLACK (WIDE)	XPBLOBW

## KIT INCLUDES:

•	BLVX/1
•	Required Monitor (see table below)
•	BLSH/1
•	DMVC/08K
•	VA/08K

ETI/XIP R/1 MINI SER PCS/XIP VAS/101

## SATIN BLACK KEYPAD X-AIR+ KIT

Panel	Monitor	Code
	AGATA VC	XPBLKAG
	PERLA BLACK	XPBLKPB
2.4	PERLA WHITE	XPBLKPW
23444	OPALE WHITE	XPBLKOW
	OPALE WHITE (WIDE)	XPBLKOWW
ē	OPALE BLACK	XPBLKOB
	OPALE BLACK (WIDE)	XPBLKOBW

### KIT INCLUDES:

ETI/XIP R/1 MINI SER PCS/XIP VAS/101

AGATA VC	PERLA BLACK	MIN.	OPALE BLACK	7	OPALE BLACK (WIDE)	
- 1	PERLA WHITE	28	OPALE WHITE	<b>F</b>	OPALE WHITE (WIDE)	

# HIGHLY POLISHED X-AIR+ KIT

Panel	Monitor	Code
	AGATA VC	XPHPAG
	PERLA BLACK	XPHPPB
	PERLA WHITE	XPHPPW
. Ü	OPALE WHITE	XPHPOW
	OPALE WHITE (WIDE)	XPHPOWW
	OPALE BLACK	XPHPOB
	OPALE BLACK (WIDE)	XPHPOBW

# HIGHLY POLISHED KEYPAD X-AIR+ KIT

Panel	Monitor	Code
	AGATA VC	XPHPKAG
-	PERLA BLACK	XPHPKPB
	PERLA WHITE	XPHPKPW
	OPALE WHITE	XPHPKOW
京田東   京田東	OPALE WHITE (WIDE)	XPHPKOWW
. 0	OPALE BLACK	XPHPKOB
	OPALE BLACK (WIDE)	XPHPKOBW

### KIT INCLUDES:

HPVX/1
Required Monitor (see table below)
HPSH/1
DMVC/08K

ETI/XIP R/1 MINI SER PCS/XIP VAS/101

### KIT INCLUDES:

HPVKX/1	•	ETI/
Required Monitor (see table below)	•	R/1
HPSH/2	•	MINI
DMVC/08k	•	PCS/
VA/08K	•	VAS/

/XIP II SER S/XIP S/101

	VA/UON		VA3/101		VA/UON		V/\3/101		
	AGATA VC		PERLA BLACK		OPALE BLACK	-	OPALE BLACK (WIDE)	Ţ	
	-	- U	PERLA WHITE	28	OPALE WHITE	- 0 -	OPALE WHITE (WIDE)	.0.	
>			•						

## CLASSIC BRASS X-AIR+ KIT

Panel	Monitor	Code		
	AGATA VC	XPBRAG		
	PERLA BLACK	XPBRPB		
	PERLA WHITE	XPBRPW		
	OPALE WHITE	XPBROW		
	OPALE WHITE (WIDE)	XPBROWW		
	OPALE BLACK	XPBROB		
	OPALE BLACK (WIDE)	XPBROBW		

### KIT INCLUDES:

BRVX/1 Required Monitor (see table below) BRSH/1

ETI/XIP R/1 MINI SER

# CLASSIC BRASS KEYPAD X-AIR+ KIT

Panel	Monitor	Code		
	AGATA VC	XPBRKAG		
	PERLA BLACK	XPBRKPB		
	PERLA WHITE	XPBRKPW		
	OPALE WHITE	XPBRKOW		
	OPALE WHITE (WIDE)	XPBRKOWW		
	OPALE BLACK	XPBRKOB		
	OPALE BLACK (WIDE)	XPBRKOBW		

### KIT INCLUDES:

BRVKX/1 Required Monitor (see table below) BRSH/1 ETI/XIP R/1 MINI SER

DMVC/08K VA/08K				<ul><li>DMVC/08K</li><li>VA/08K</li></ul>		PCS/XIP VAS/101	
AGATA VC	<b> </b>	PERLA BLACK		OPALE BLACK		OPALE BLACK (WIDE)	
-		PERLA WHITE	48	OPALE WHITE		OPALE WHITE (WIDE)	